aiwa SERVICE

HV-GX770 K



SERVICE MANUAL

VIDEO CASSETTE RECORDER BASIC VIDEO MECHANISM : OVD-6

This Service Manual contains information about the difference between HV-GX900 (TYPE:K).
If requiring the other information, see Service Manual of the HV-GX900 (TYPE:K)
(S/M Code No. 09-975-331-5N1).

aiwa

S/M Code No. 09-975-331-5S1

DATA

MECHANICAL REPLACEMENT PARTS LIST

REF. NO.	HV-GX900		HV-GX770	
	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
601	S4-D10-5B7-200	CAB,FRONT ASS'Y	S4-D15-2B7-200	CAB,FRONT ASS'Y
605	S3-5WP-D06-050	BUTTON,FF	S3-5WP-JA1-380	BUTTON,FF
606	S3-5WP-D06-060	BUTTON,REW	S3-5WP-JA1-390	BUTTON,REW
611	S3-5WP-D06-070	BUTTON,BASE	S3-5WP-BA0-660	BUTTON,BASE
613	----	CAB,FRONT	----	CAB,FRONT
614	S1-1WP-D05-350	PLATE,DISPLAY	S1-1WP-DA2-430	PLATE,DISPLAY
615	S1-2WP-J05-910	FLAP	S1-2WP-JA5-100	FLAP
616	S3-5WP-D05-650	BUTTON,PLAY	S3-5WP-DA2-680	BUTTON,PLAY
618	S3-5WP-D06-030	BUTTON,REC	S3-5WP-JA1-360	BUTTON,REC
619	S3-5WP-D06-040	BUTTON,STOP/EJECT	S3-5WP-JA1-370	BUTTON,STOP/EJECT
622	S3-5WP-D06-080	BUTTON,PAUSE	S3-5WP-JA1-410	BUTTON,PAUSE
625	----	SHEET,RATING	----	SHEET,RATING
628	S3-5WP-D06-090	RING,OTPB	S3-5WP-BA0-680	RING,OTPB
629	S3-5WP-D06-250	BUTTON,POWER	S3-5WP-BA0-670	BUTTON,POWER
630	S3-5WP-D06-260	BUTTON,CHANNEL	S3-5WP-JA1-400	BUTTON,CHANNEL

ACCESSORY REPLACEMENT PARTS LIST

REF. NO.	HV-GX900		HV-GX770	
	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
3	S4-D10-501-000	INSTRUCTION BOOK	S4-D15-201-000	INSTRUCTION BOOK

アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)
AIWA CO.,LTD. 2–11, IKENOHATA 1–CHOME, TAITO-KU, TOKYO 110-8710, JAPAN TEL:03 (3827) 3111

920074
Printed in Singapore